

***Carrara Foundation & Finish Tape Application Guidelines
for Vertical & Horizontal Joints or Seams***



Use a 4-6" Mud knife to lay down the 1st pass of **AcraCream** for the Foundation Tape



Lay the **Foundation Tape** into the AcraCream



Pull the knife down the **Foundation Tape** to remove any air bubbles. Make sure the Foundation tape is flat and fully adhered



Trowel a 2nd pass of **AcraCream** to completely cover the Foundation tape



Center the **Finish Tape** over the Foundation tape, into the wet AcraCream.



Pull the knife down the **Finish Tape** making sure the tape is flat and fully adhered



Float a light coat of AcraCream 9-12" from the center to each edge to minimize any center bump. Total float width 18-24" (like a drywall butt joint)



Apply enough **AcraCream** to hide the black reinforcing threads of the **Finish Tape**.

Don't overlap the Foundation tape at the intersection of horizontal & vertical seams